

# How to Paint Your Home Exterior – Step by Step



*Warm Welcome*

**Plascon**

**PAINT | EXPERT**

An exterior palette that feels like home from the very first glance.

1

## Step 1: Choose Your Colour Palette

The **Warm Welcome** palette by Plascon Paint Expert adds natural elegance and balance to any home:

- **Walls:** Plascon Barn Owl (07-E2-3)
- **Trims:** Plascon Dried Leaf (25)
- **Accents:** Plascon Tibetan Cloak (GR-R03)
- **Roof:** Plascon Nuroof Cool Ashen Sky (TRP214)
- **Optional Feature Door:** Plascon Burgundy Berry (P7-C1-1)

**Walls:** Barn Owl (07-E2-3)

**Trims:** Dried Leaf (25)

**Accents:** Tibetan Cloak (GR-R03)

**Roof:** Ashen Sky (TRP214)

**Optional:** Burgundy Berry (P7-C1-1)

2

## Step 2: Prepare the Surfaces

- Inspect for flaking paint and cracks
- Clean thoroughly with a brush or pressure washer
- Repair with Polycell Exterior Crack Filler
- Sand patched areas until smooth

### Hamilton's Recommended Tools:

- **Hamilton's Professional Scraper** – remove flaky old paint or debris.
- **Hamilton's Wet & Dry Sanding Sheet** – smooth down filler and prep surfaces before priming.

3

## Step 3: Prime for Better Results

- Use **Plascon Plaster Primer (UC56)** for raw or newly repaired plaster



4

**Step 4: Paint the Roof**

Use **Plascon Nuroof Cool in Cool Ashen Sky (TRP214)** – designed to reflect solar heat and reduce indoor temperatures.

**Hamilton's Recommended Tools:**

- **Hamilton's Corrugated Roof Roller** – specifically designed for corrugated surfaces
- **Hamilton's Specialist Roof Block Brush** – great for cutting in around flashing, gutters, or tricky areas.

5

**Step 5: Paint the Walls**

Paint your walls with **Plascon Wall & All** for superior protection and a low-sheen, washable finish.

**Colour: Barn Owl (07-E2-3)**

**Hamilton's Recommended Tools:**

- **Hamilton's Plascon Wall & All Roller Trayset**
- **Hamilton's Pro-Finish Extension Pole**
- **Hamilton's Utility Brushes** – for cutting in at corners and edges with precision

6

**Step 6: Add Detail with Trims and Accents**

Use **Plascon Velv glo Water-Based** on wood or metal trims, fascia boards, and window surrounds.

**Colour: Dried Leaf (25)**

**Optional Accent: Tibetan Cloak (GR-R03)** on features like shutters or pergola beams

**Hamilton's Recommended Tools:**

- **Hamilton's Velour Trayset**
- **Hamilton's Perfection Ensign Angled Brush**

7

**Optional Step: Feature Front Door in Burgundy Berry**

Add dramatic contrast with **Plascon Burgundy Berry (P7-C1-1)** on your front door.

For a cohesive look, echo the colour in outdoor planters or accessories.

**Need Help or Colour Samples?**

Visit your local Plascon Paint Expert store for:

- Swatches & brush-outs
- Product advice tailored to your project
- Tool recommendations
- On-site colour guidance if needed

**Find your store at**  
**[www.paintexpert.co.za](http://www.paintexpert.co.za)**

TIPS

**Quick Tips for a Great Paint Job**

- ☒ Paint between 10am to 3pm on dry days
- ☒ Don't paint if rain is expected within 6 hours
- ☒ Always follow drying time instructions between coats
- ☒ Work top-down: roof → walls → trims → accents
- ☒ Use Hamilton's tools for best performance and smooth results

